



Time-Keeper MAX
Web Interface Update




Table Of Contents


Time-Keeper® Max Web Interface Update	2
---	---

Time-Keeper® Max Web Interface Update

To update the Time-Keeper MAX Web Interface you will need the Update.exe application included with the unit. Update.exe is a Windows Only Application. To get started all you need to do is double click the Update.exe application. You will see the following screen:




Click the Find button to discover your Time-Keeper MAX Web Interface. You will see the following screen:




Click(Select) and highlight the discovered you would like to update and click the OK button.



Next click the Browse button to browse to the location you downloaded or saved the Time-Keeper MAX Web Interface software update. A screen similar to the following will be displayed:




Select the software update you would like to apply and click the Open button. The following screen will be displayed. Verify the Reboot when complete box is checked and click the Update button.




Time-Keeper® Max Web Interface Update Complete

After the update has been applied successfully the following screen will be displayed and the process is complete.



If you receive the following screen after a couple of attempts and you are unable to update please contact TouchPlate Lighting Controls for further assistance.





Time Keeper MAX Web Interface Update
Revision: 1.0a



www.touchplate.com

1830 Wayne Trace • Fort Wayne, Indiana 46803 • 260.426.1565