

OLD SWITCH:



**1 Button Rocker**

REPLACE WITH:



**ULT-2B-0L**





**5002**



**ECL-2B-0L**

### TOUCHPLATE REPLACEMENT GUIDE FOR THREE WIRE LOW VOLTAGE ROCKER SWITCHES



**2 Button Rocker**





**ULT-4B-0L**



**CLA-4B-0L**



**ECL-4B-0L**



**3 Button Rocker**



**ULT-6B-0L**



**CLA-6B-0L**

