



TOUCHPLATE REPLACEMENT GUIDE FOR THREE WIRE LOW VOLTAGE ROCKER SWITCHES




1 Button Rocker



Replace with 500S1-0200A




Wiring detail to 3 wire switch




2 Button Rocker



Replace with CLAS1-0400A




Wiring Detail to 3 wire switch



3 Button Rocker



Replace with CLAS1-0600A



Wiring Detail to 3 wire switch