



3-WIRE 4 BUTTON ROCKER TO TOUCH-PLATE MYSTIQUE 8 BUTTON SWITCH WIRING



SCREW TERMINAL 1 ← EXISTING RED #1

SCREW TERMINAL SC ← EXISTING WHITE

SCREW TERMINAL 5 ← EXISTING GREEN #1

SCREW TERMINAL 2 ← EXISTING RED #2

SCREW TERMINAL SC ← EXISTING WHITE

SCREW TERMINAL 6 ← EXISTING GREEN #2

SCREW TERMINAL 3 ← EXISTING RED #3

SCREW TERMINAL SC ← EXISTING WHITE

SCREW TERMINAL 7 ← EXISTING GREEN #3

SCREW TERMINAL 4 ← EXISTING RED #4

SCREW TERMINAL SC ← EXISTING WHITE

SCREW TERMINAL 8 ← EXISTING GREEN #4