

OLD SWITCH:

REPLACE WITH:

TOUCHPLATE REPLACEMENT GUIDE FOR THREE WIRE LOW VOLTAGE ROCKER SWITCHES





1 Button Rocker

ULTS1-0200A

500S1-0200A

ECLS1-0200A





2 Button Rocker

ULTS1-0400A

CLAS1-0400A

ECLS1-0400A



3 Button Rocker

ULTS1-0600A

CLAS1-0600A

